

VISION GLASS TREATMENT



DIRECTIONS:

STEP 1: Clean *Do not use in direct sunlight.* **1)** Spray Pryme on any glass surface one half at a time, scrape section using plastic razor blade to remove unwanted debris. **2)** Use microfiber towel to remove any residue created from the scrapping process. **3)** Repeat steps 1 and 2 until entire surface has been cleaned.

STEP 2: Apply Hold the applicator between the thumb and fingers with the pad down and level over the windshield. Squeeze the wings together until a popping sound is heard and liquid is released onto the pad. Use immediately.

Wipe the soft pad of the applicator over the glass up and down then side to side to ensure the glass is well covered. Avoid painted surfaces. Remove liquid from non-glass surfaces with dry paper towel.

STEP 3: Dry Wipe the glass with a clean dry paper towel immediately after glass treatment has been applied to the entire windshield. Product may start to haze, use a clean microfiber towel to buff away any hazed treatment. Dispose of applicator and paper towel.

PLEASE NOTE: One single-use applicator will treat one windshield or two side windows.

- Do not let Vision Glass Treatment air dry onto windshield.
- When applying to large surface areas treat and dry one half at a time.
- Application conditions: Do not use in temperatures colder than 50° F or hotter than 90° F. For excessively humid conditions, apply glass treatment indoors.
- Once applied, Vision Glass Treatment can be reapplied as needed.
- Cleaning glass with ordinary glass cleaners will not affect product durability.

GLASS TREATMENT KIT

PART # 62941

