

BANISH RODENT DETERRENT



APPLICATION INSTRUCTIONS

PLEASE READ BEFORE USE: **1. READ THE LABEL :** ALWAYS READ AND FOLLOW THE INSTRUCTIONS ON THE PRODUCT LABEL CAREFULLY BEFORE USE. THIS INCLUDES INFORMATION ON USAGE, SAFETY PRECAUTIONS, AND PROPER DISPOSAL. **2. PERSONAL PROTECTIVE EQUIPMENT (PPE) :** WHEN APPLYING RODENT SPRAY, IT IS RECOMMENDED TO WEAR APPROPRIATE PPE SUCH AS GLOVES, GOGGLES, AND A PARTICULATE MASK TO PREVENT EXPOSURE. **3. VENTILATION :** IF APPLYING INDOORS, ENSURE THERE IS GOOD VENTILATION. OPEN THE WINDOWS AND DOORS TO ALLOW FRESH AIR TO CIRCULATE AND REDUCE ANY CONCENTRATION OF FUMES. **4. LOW VOLUME SETTING :** SET THE SPRAY NOZZLE TO A LOW VOLUME TO MINIMIZE THE SPREAD OF THE PRODUCT, REDUCE MESS, AND REDUCE EXPOSURE. **5. STORE PROPERLY :** STORE THE RODENT SPRAY IN A SECURE LOCATION AWAY FROM THE REACH OF CHILDREN AND PETS, AND IN ACCORDANCE WITH THE MANUFACTURER'S RECOMMENDATIONS. **6. PROPER DISPOSAL :** DISPOSE OF EMPTY CONTAINERS AND ANY UNUSED PRODUCT ACCORDING TO LOCAL REGULATIONS AND MANUFACTURER GUIDELINES. **7. SAFETY TRAINING:** IF YOU'RE NOT EXPERIENCED WITH USING RODENT SPRAY, CONSIDER GETTING GUIDANCE OR TRAINING ON ITS SAFE AND PROPER USAGE TO MINIMIZE RISKS. **8. EMERGENCY PREPAREDNESS :** HAVE A PLAN IN CASE OF ACCIDENTAL EXPOSURE. KNOW THE LOCATION OF THE NEAREST MEDICAL FACILITY AND KEEP EMERGENCY CONTACT NUMBERS HANDY.

- 01** **FOR BEST RESULTS** - Remove any nesting and clean the area being treated before application, blow-off / remove dirt and grime for maximum adhesion of the product.
- 02** Shake bottle before each use and use in a well ventilated area. We recommend utilizing personal protective equipment (PPE) to minimize the risk of potential hazards.
- 03** Attach a compressed air line to the air fitting on the Universal Misting Gun.
- 04** Insert the suction tube attached to the Misting Gun into a bottle of BANISH and secure it by tightening the cap.
- 05** Use the blue adjustment knob to the lowest setting. Spray an even coat on any wires and crevices found in, around, and under the engine compartment.
- 06** Evenly coat any exposed wires harnesses or entry points found in wheel wells, surrounding undercarriage, and bumpers.
- 07** **WARNING:** Avoid spraying product directly on exhaust components.
- 08** Close hood and check windshield for any overspray.
If found, spray with glass cleaner and wipe away with a clean rag.

