

IMPROVED VISION



INSTALLATION INSTRUCTIONS - VISION GLASS TREATMENT

KIT INCLUDES:

Surface Prep Glass Cleaner (x1) | Plastic Razor (x1) | Vision Glass Treatment (x1) | Clean Tab - Concentrated windshield washer tablet (x1) | Lint-Free Microfiber Towel (x2) PN - 62941

STEP 1 - CLEAN:

Glass surfaces should be clean, dry and out of direct sunlight before and during the application process. 1) Surface Preparation: Spray the glass surface with MP Pryme until completely covered. Using the plastic razor blade provided, scrape glass surface to remove contaminants, and embedded debris. 2) Wipe dry with a clean microfiber towel to ensure a clean and smooth surface. 3) Repeat steps 1 and 2 as needed.

STEP 2 - APPLICATION:

1) Apply a generous amount of MP Vision Glass Treatment onto applicator provided. 2) Spread evenly on glass surface, working the product onto the glass using a crosshatch (side-to-side, then up-and-down) pattern for uniform coverage.

STEP 3 - DWELL TIME:

1) Spread evenly on glass surface, working the product onto the glass using a crosshatch (side-to-side, then up-and-down) pattern for uniform coverage. 2) Wipe off product using a clean, dry microfiber towel. Be sure to remove all product, revealing a clear, hydrophobic finish.

PLEASE NOTE:

- One single-use applicator will treat one windshield and two side windows.
- When applying to large surface areas treat and dry one half at a time.
- Once applied, Vision Glass Treatment can be reapplied as needed.
- Cleaning glass with ordinary glass cleaners will not affect product durability.
- Application conditions: Colder temperatures or excessively humid conditions, may require an extended dry time.
- For best results, allow coating to cure for at least 6-12 hours before exposing to any water, moisture, or cleaning products.

